

## **Portable Add-ons Everywhere Power 3500 Device Compatibility (as at 25/08/2005)**

### **A01**

Nokia 1100, Nokia 1108, Nokia 1221, Nokia 1260, Nokia 1261, Nokia 2100, Nokia 2112, Nokia 2115i, Nokia 2116, Nokia 2260, Nokia 2270, Nokia 2275, Nokia 2280, Nokia 2285, Nokia 2300, Nokia 252, Nokia 2600, Nokia 2650, Nokia 282, Nokia 3100, Nokia 3105, Nokia 3108, Nokia 3120, Nokia 3200, Nokia 3205, Nokia 3210, Nokia 3220, Nokia 3230, Nokia 3285, Nokia 3300, Nokia 3310, Nokia 3315, Nokia 3330, Nokia 3350, Nokia 3360, Nokia 3361, Nokia 3390, Nokia 3395, Nokia 3410, Nokia 3510, Nokia 3510i, Nokia 3520, Nokia 3530, Nokia 3560, Nokia 3570, Nokia 3585, Nokia 3585i, Nokia 3586, Nokia 3586i, Nokia 3587i, Nokia 3588i, Nokia 3589i, Nokia 3590, Nokia 3595, Nokia 3600, Nokia 3610, Nokia 3620, Nokia 3650, Nokia 3660, Nokia 5100, Nokia 5120, Nokia 5125, Nokia 5140, Nokia 5160, Nokia 5165, Nokia 5170i, Nokia 5180i, Nokia 5185i, Nokia 5190, Nokia 5210, Nokia 5300, Nokia 5510, Nokia 6010, Nokia 6015, Nokia 6015i, Nokia 6016i, Nokia 6020, Nokia 6021, Nokia 6030, Nokia 6100, Nokia 6108, Nokia 6120, Nokia 6160, Nokia 6161, Nokia 6162, Nokia 6170, Nokia 6185i, Nokia 6190, Nokia 6200, Nokia 6210, Nokia 6220, Nokia 6225, Nokia 6230, Nokia 6230i, Nokia 6250, Nokia 6255i, Nokia 6260, Nokia 6310, Nokia 6310i, Nokia 6340, Nokia 6340i, Nokia 6360, Nokia 6370, Nokia 6385, Nokia 640, Nokia 650, Nokia 6510, Nokia 6560, Nokia 6585, Nokia 6590, Nokia 6590i, Nokia 6600, Nokia 6610, Nokia 6610i, Nokia 6620, Nokia 6630, Nokia 6650, Nokia 6651, Nokia 6670, Nokia 6680, Nokia 6681, Nokia 6800, Nokia 6810, Nokia 6820, Nokia 6822, Nokia 7110, Nokia 7160, Nokia 7190, Nokia 7200, Nokia 7210, Nokia 7250, Nokia 7250i, Nokia 7260, Nokia 7270, Nokia 7280, Nokia 7600, Nokia 7610, Nokia 7650, Nokia 7710, Nokia 8210, Nokia 8250, Nokia 8260, Nokia 8265, Nokia 8265i, Nokia 8270, Nokia 8280, Nokia 8290, Nokia 8310, Nokia 8390, Nokia 8810, Nokia 8850, Nokia 8850 Gold, Nokia 8855, Nokia 8860, Nokia 8890, Nokia 8910, Nokia 8910i, Nokia 9200, Nokia 9210i, Nokia 9290, Nokia 9300, Nokia 9500, Nokia HDW-3, Nokia HS-11W, Nokia HS-3W, Nokia HS-4W, Nokia N-Gage, Nokia N-GageQD, Nokia THR850, Nokia THR880, Nokia 6101

### **A08**

Siemens A52, Siemens A55, Siemens A56, Siemens A57, Siemens A60, Siemens A65, Siemens C55, Siemens C56, Siemens C60, Siemens C61, Siemens C62, Siemens C65, Siemens CF62, Siemens CT56, Siemens CX65, Siemens M55, Siemens M56, Siemens M65, Siemens MC60, Siemens S55, Siemens S56, Siemens S57, Siemens S65, Siemens SF65, Siemens SK65, Siemens SL55, Siemens SL56, Siemens SL65, Siemens SX1, Siemens CFX65, Siemens CT66, Siemens SL65 ESCADA

### **A09**

Sony Ericsson A2218z, Sony Ericsson K700i, Sony Ericsson P800, Sony Ericsson P910a, Sony Ericsson R300, Sony Ericsson R380 WORLD, Sony Ericsson S700i, Sony Ericsson S710a, Sony Ericsson T100, Sony Ericsson T200, Sony Ericsson T226, Sony Ericsson T230, Sony Ericsson T237, Sony Ericsson T28 WORLD, Sony Ericsson T28z, Sony Ericsson T300, Sony Ericsson T306, Sony Ericsson T310, Sony Ericsson T316, Sony Ericsson T39, Sony Ericsson T39m, Sony Ericsson T60, Sony Ericsson T606, Sony Ericsson T608, Sony Ericsson T60i, Sony Ericsson T61, Sony Ericsson T610, Sony Ericsson T616, Sony Ericsson T61c, Sony Ericsson T61d, Sony Ericsson T61LX, Sony Ericsson T61z, Sony Ericsson T62U, Sony Ericsson T630, Sony Ericsson T637, Sony Ericsson T68, Sony Ericsson T68i, Sony Ericsson T68m, Sony Ericsson Z200, Sony Ericsson Z500a, Sony Ericsson Z600, Sony Ericsson HBH-200, Sony Ericsson HBH-35, Sony Ericsson HBH-65, Sony Ericsson J200c, Sony Ericsson J210c, Sony Ericsson J300c, Sony Ericsson K300c, Sony Ericsson K300i, Sony Ericsson K500c, Sony Ericsson K506c, Sony Ericsson K508c, Sony Ericsson K700c, Sony Ericsson P802, Sony Ericsson P900, Sony Ericsson P908, Sony Ericsson P910a, Sony Ericsson P910c, Sony Ericsson P910i, Sony Ericsson S700c, Sony Ericsson T106, Sony Ericsson T290c, Sony Ericsson V800, Sony Ericsson Z1010, Sony Ericsson Z208, Sony Ericsson Z608, Sony Ericsson Akono HBH-300, Sony Ericsson Akono HBH-600, Sony Ericsson Akono HBH-602, Sony Ericsson Akono HBH-660, Sony Ericsson Akono K500i

## **A10**

Motorola 388c, Motorola A1000, Motorola A630, Motorola A760, Motorola A830, Motorola A835, Motorola A840, Motorola A845, Motorola A860, Motorola A920, Motorola A925, Motorola C331, Motorola C332, Motorola C333, Motorola C341, Motorola C343, Motorola C343c, Motorola C353, Motorola E310, Motorola E380, Motorola HF800, Motorola HS805, Motorola HS810, Motorola HS820, Motorola HS850, Motorola i30sx, Motorola i35s, Motorola i50sx, Motorola i55sr, Motorola i55sx, Motorola i58sr, Motorola i80s, Motorola i85s, Motorola i88s, Motorola i90c, Motorola i90cse, Motorola i95cl, Motorola iM1000, Motorola MPx220, Motorola T300p, Motorola T720, Motorola T720i, Motorola T721, Motorola T722, Motorola T722i, Motorola T725, Motorola T725G, Motorola T730, Motorola T731, Motorola Timeport 270c, Motorola Timeport P280, Motorola V120, Motorola V120c, Motorola V120e, Motorola V120t, Motorola V120x, Motorola V200, Motorola V260, Motorola V262, Motorola V265, Motorola V300, Motorola V400, Motorola V500, Motorola V505, Motorola V551, Motorola V60, Motorola V600, Motorola V60c, Motorola V60g, Motorola V60i, Motorola V60p, Motorola V60s, Motorola V60t, Motorola V60t Color, Motorola V60x, Motorola V65p, Motorola V65s, Motorola V66, Motorola V70, Motorola V710, Motorola V810, Motorola V980, Motorola C975, Motorola C980, Motorola E1000, Motorola E398, Motorola E815, Motorola V330, Motorola V510, Motorola V535, Motorola V550, Motorola V555, Motorola V600i, Motorola V620, Motorola V635, Motorola V80

## **A19**

palmOne i705, palmOne m125, palmOne m130, palmOne m500, palmOne m505, palmOne m515, palmOne Tungsten C, palmOne Tungsten T, palmOne Tungsten T2, palmOne Tungsten T3, palmOne Tungsten W, palmOne Zire 71

## **A20**

Compaq/HP iPAQ h1700, Compaq/HP iPAQ h1910, Compaq/HP iPAQ h1915, Compaq/HP iPAQ h1920, Compaq/HP iPAQ h1930, Compaq/HP iPAQ h1935, Compaq/HP iPAQ h1937, Compaq/HP iPAQ h1940, Compaq/HP iPAQ h1945, Compaq/HP iPAQ h2210, Compaq/HP iPAQ h2215, Compaq/HP iPAQ h3630, Compaq/HP iPAQ h3635, Compaq/HP iPAQ h3641, Compaq/HP iPAQ h3650, Compaq/HP iPAQ h3660, Compaq/HP iPAQ h3670, Compaq/HP iPAQ h3730, Compaq/HP iPAQ h3760, Compaq/HP iPAQ h3765, Compaq/HP iPAQ h3830, Compaq/HP iPAQ h3835, Compaq/HP iPAQ h3850, Compaq/HP iPAQ h3860, Compaq/HP iPAQ h3870, Compaq/HP iPAQ h3875, Compaq/HP iPAQ h3950, Compaq/HP iPAQ h3955, Compaq/HP iPAQ h3970, Compaq/HP iPAQ h3975, Compaq/HP iPAQ h4150, Compaq/HP iPAQ h4155, Compaq/HP iPAQ h4350, Compaq/HP iPAQ h4355, Compaq/HP iPAQ h5450, Compaq/HP iPAQ h5455, Compaq/HP iPAQ h5550, Compaq/HP iPAQ h5555, Compaq/HP iPAQ h6315, Compaq/HP iPAQ hx2110, Compaq/HP iPAQ hx2410, Compaq/HP iPAQ hx2415, Compaq/HP iPAQ hx2750, Compaq/HP iPAQ hx2755, Compaq/HP iPAQ hx4700, Compaq/HP iPAQ hx4705, Compaq/HP iPAQ rx3115, Compaq/HP iPAQ rx3400, Compaq/HP iPAQ rx3715, Compaq/HP iPAQ rz1710, Compaq/HP iPAQ rz1715

## **A29**

Jens of Sweden MP-400, Kodak EasyShare picture viewer, Rim Blackberry 5790, Rim Blackberry 5820, Rim Blackberry 6210, Rim Blackberry 6220, Rim Blackberry 6230, Rim Blackberry 6280, Rim Blackberry 6510, Rim Blackberry 7100g, Rim Blackberry 7100r, Rim Blackberry 7100t, Rim Blackberry 7100v, Rim Blackberry 7100x, Rim Blackberry 7210, Rim Blackberry 7230, Rim Blackberry 7250, Rim Blackberry 7280, Rim Blackberry 7290, Rim Blackberry 7510, Rim Blackberry 7520, Rio Carbon

## **B01**

Apple iPod, Apple iPod Mini, Apple iPod Photo, Apple iPod U2, HP iPod,